

HOT TUB INSTRUCTIONS

VERY IMPORTANT TO READ ALL INSTRUCTION ATTENTIVELY. IF YOU DON'T FOLLOW INSTRUCTIONS, IN CASE OF DAMAGE NO GUARANTEE WILL BE APPLIED.

PREPARATION FOR USING:

- Before using wooden hot tub for the first time it must be soaked with water.
 - For wooden tubs with plastic or glass fiber input soaking process is unnecessary.
- Soaking process:** Close the hole of water outlet, then pour about 10-50 liters of water on the walls and the bottom of the tub. After 2-4 hours repeat the process. Then fill all the tub with water. At the beginning water will break through, but after soaking process the tub will become sealed. Soaking process have to last 2-4 days. After soaking the hot tub please release a little bite the bands.
- In summer time it is recommended to keep the water in the tub to avoid wood drying up. During the warm seasons, the water should be changed regularly.
 - In winter time it is necessary to keep tub without water, because frozen ice can break the tub.
 - The basis on which the tub would stand, must be hard.
 - Usually the water level is 10-15 cm from the top edge, when using the hot tub. So that when you get in the tub, the water won't run over the edges.
 - For cleaning use sanitary measures for maintenance of swimming pools (from bacteria and so on).
 - Before fired up the heater, **heater must be drowned with the water!!!** Otherwise heater can be damaged.
 - The tub will serve for longer time, if the wood will be treated from outside.

SAFETY:

- When using the hot tub it is very important to follow local safety regulations, in order to avoid any risks to human health or property.
- For fire safety purposes, place the hot tub at a distance of at least 2-4 m from any building. Follow the safety requirements in each case individually, depending on your local area rules.
- Never leave the hot tub's stove unattended while heating.
- While the stove is being fired, the chimney and the stove are hot and may cause burns when touched.
- Make sure that the number of users in the hot tub does not exceed the permitted number of people.
- When firing the stove, heat the water in the hot tub to a recommended maximum of + 38 °C / +41°C.
- Never jump into the hot tub.
- Never leave children unsupervised in the hot tub.
- Never use abrasive cleaning agents to clean the hot tub.
- In winter, always drain the hot tub and stove after use to prevent any subsequent freezing of water in the tub or its pipes.

HEATING THE HOT TUB:

- Firing of the stove may begin only after the hot tub has been filled with water!
- Water may be drained from the hot tub only after the embers in the stove have been fully extinguished!
- Before filling the hot tub with water make sure that the drain valve of the hot tub is closed.
- Fill the hot tub to a level where the water is approximately 10 cm over the section above the stove.
- Using only dry wood to fire the hot tub's stove. Coal can't be used.
- To heat water faster, it is advisable to cover the hot tub with a lid.
- It is recommending to heat the water in the hot tub to a maximum of + 38 °C / +41°C.
- Pay attention to the recommendations used for water contact with the stainless steel heater. Metal code you will find on the heater or in the purchase documents.
 - HEATER AISI 430 - suitable for use only with fresh water, no chemistry or salt.
 - HEATER AISI 304 - suitable for use only with fresh water and a little bit chlorine.
 - HEATER AISI 316 - suitable for use with sea water and a little bit chlorine.

MAINTENANCE OF THE HOT TUB:

- Cleaning and maintaining the hot tub regularly is important in terms of both hygiene and the long term preservation.
- It is advisable to wash the hot tub after each use.
- It is advisable to shower before using the hot tub, to ensure better hygiene in the water.
- Do not wash the hot tub to the high-pressure washer, use household detergents and a soft cloth to clean it.
- No material with a rough surface or chlorine-containing cleaning agents should be used to clean the hot tub.
- In winter, always drain the water from the hot tub and stove after using it.
- Water freezing may cause the hot tub or stove to break. Using salt or chlorine cause big damage to stove too!

Caution! Fire and hot water may lead to bad injuries! Never leave your children unattended! Do not leave the Hot Tub unattended as long as the fire is burning in the stove!